

GUIDELINES

Welcome to Cell C Fibre!

You have just received your new router. Before you enjoy your high speed, uncapped connectivity, here's a quick guide to get you going:

WHAT'S IN THE BOX?




FOLLOW THESE EASY STEPS TO CONNECT YOUR ROUTER:

NB: Please do not turn your Router ON until you have all cables connected.



Step 1

Firstly, take your Router out of the box and connect the Power Adaptor.



Step 2

Connect one end of the Yellow Ethernet/LAN cable in the Red WAN port on the back of your Technicolor Router.



Step 3

Connect the other end of the Yellow Ethernet Cable to the Fibre box installed by the network provider. NB: Connect the Cable to LAN1/GE1 if the Fibre box has more than one port.



Step 4

Once all cables are connected, you can now switch on the Router. Leave the router for 5-10 minutes for all lights to be on, as shown below.



Step 5

Connect your mobile phone or personal computer using the wireless details under the Router and enjoy your internet!

CONTACT OUR CELL C FIBRE SUPPORT

084 143 4273 | cfibresupport@cellc.co.za

